



## EK 35/4 Battery powered hydraulic crimping tool 6 - 150 mm<sup>2</sup>

### Description

- > Large cross section range up to 150 mm<sup>2</sup>
- > Slim crimping head - ideal when space is critical
- > All tool data in view thanks to display and i-press® app

### Characteristics

- > Choose your battery system: Bosch or Makita
- > All data can be easily read via Bluetooth
- > Closed head, flip top style, rotatable
- > Quality assurance via visual and audible signals in case of error
- > Simple and safe: One-button operating concept for controlling all tool functions
- > Simple and safe: Automatic retraction when operation is complete
- > Effortless working thanks to low weight
- > LED for work area illumination
- > Always ready-to-use thanks to battery charge and service display

### Suitable for

- > 4-series interchangeable crimping dies, narrow crimping

## Articles

Battery powered hydraulic crimping tool 6 - 150 mm<sup>2</sup> with Bosch battery

Part No. Bosch

EK354CFB

Battery powered hydraulic crimping tool 6 - 150 mm<sup>2</sup> with Makita battery

Part No. Makita

EK354CFM

## Technical Data

	Bosch battery system	Makita battery system
Crimping force	35 kN	35 kN
Stroke	9 mm	9 mm
Crimping range	6-150 mm <sup>2</sup>	6-150 mm <sup>2</sup>
Crimping cycle	3 s to 4 s (depending on cross-section)	3 s up to 4 s (depending on cross-section)
Number of crimps	approx. 140 at 120 mm <sup>2</sup> Cu	approx. 140 at 120 mm <sup>2</sup> Cu
Battery voltage (V)	18 V	18 V
Battery capacity	2.0 Ah, Li-Ion	1.5 Ah, Li-Ion
Charging time	15 min.	15 min.
Weight incl. battery	2.4 kg	2.4 kg
Ambient temperature	-10°C to +40 °C	-10°C up to +40 °C